



# Puppy Glove™

## Poly Pet Station - Poly Post

### INSTALLATION INSTRUCTIONS


# 415241

### Box 1 Includes:



■ **Aluminum Pet Sign**

#### BAG B




■ **BAG B:**  
 • 2 - 2-1/4" Bolts  
 • 2 - Washers  
 • 2 - Locknuts



■ **Poly Trash Receptacle (10 Gallon)**  
 ■ **Attached Lid**

#### BAG D



■ **BAG D:**  
 • 2 - 2-1/2" Bolts  
 • 2 - Fender Washers  
 • 2 - Washers  
 • 2 - Locknuts




■ **2 Keys for Dispenser (inside the dispenser)**




■ **Poly Bag Dispenser**

#### BAG C



■ **BAG C:**  
 • 2 - 2-1/2" Bolts  
 • 4 - Washers  
 • 2 - Locknuts



■ **3 Boxes of Waste Pick Up Bags\***



■ **1 Box of Trash Receptacle Liner Bags\***


\*Trash receptacle liner bags and waste pick-up bags may be sent in a separate shipping box.

### Box 2 Includes:


(Separate Shipping Box)

■ **8' Telescopic Poly Mounting Post**  
 Small - 1-3/4" x 1-3/4" x 4'  
 Large - 2" x 2" x 4'

#### BAG A



■ **BAG A Contents:**  
 • 2 - Carriage Bolts (2-1/2" x 5/16")  
 • 2 - Washers  
 • 2 - Locknuts



**PLEASE CHECK THE CONTENTS OF THE BOXES AND CALL CHADWELL SUPPLY IF ANY PARTS ARE MISSING.**

**ChadwellSupply.com | 888.341.2423**



# Puppy Glove™

# 415241

## Poly Pet Station - Poly Post INSTALLATION INSTRUCTIONS

### CHOOSE A SPOT!

Pick a visible location in your community for the Puppy Glove™ Pet Station.

### INSTALL THE MOUNTING POST

- Separate the smaller post 1¼" x 1¼" x 4' from the larger post 2" x 2" x 4' (fig. 1).
- Dig an 18 inch deep by 8 inch wide hole (fig. 2).
- Insert the larger post (2" x 2" x 4') about 12¾" into the hole.
- Make sure the post is level and plum (vertical position).
- Mix concrete (not included), following manufacturer instructions, then fill the hole with concrete.
- Let the concrete dry for at least 12 hours.





### ATTACH THE TOP POST

- Slide the smaller post into the larger cemented post until the first 2 holes align (fig. 3).
- Secure the posts together with enclosed carriage bolts, washers, and locknuts (Bag A) (fig. 4).
- Install the bolts in the first 2 overlapping holes with the bolts pointing front to back.
- Once assembled, the total height of the telescopic post should be about 6'6" (fig. 6).

**NOTE:** The 4th hole down from the top of the 2" post is for installation of the Puppy Glove Poly Trash Receptacle.

### ATTACH THE SIGN

- Mount the Puppy Glove™ Pet Sign to the top of the 1¼" post, with the top hole of the sign matching the top hole in the post.
- Secure with the enclosed 2¼ bolts, washers and locknuts (Bag B) (fig. 5).





# Puppy Glove™

## Poly Pet Station - Poly Post

### INSTALLATION INSTRUCTIONS

415241

#### ATTACH THE BAG DISPENSER

- Remove the two keys located inside the dispenser.
- Insert key into the universal cam lock on the front access panel. Turn the key a quarter turn to the right or left.
- Install the Puppy Glove™ Poly Bag Dispenser below the sign, using the next two holes under the sign.

**NOTE:** The 2½" bolt is to be installed with an exterior washer in the top mounting hole of the Dispenser.

#### DO NOT OVER-TIGHTEN TO AVOID POSSIBLE CRACKING OF DISPENSER UNIT

- Gently pull the bottom of the front access panel about 2 inches towards you and lift to release and separate the front access panel from the body of the dispenser.
- Locate the two pre-drilled holes on the back wall of the dispenser.
- Align the two pre-drilled holes in the dispenser with the holes on the telescopic post and secure with the enclosed bolts, washers and locknuts (Bag C) (fig. 6).

#### FILL/REFILL THE BAG DISPENSER

- To fill/refill the dispenser with Puppy Glove™ Waste Pick Up Bags, take the 3 boxed rolls, and tear off the perforated seal from each box.
- Place the 3 boxes next to each other vertically on the shelf inside the body of the dispenser with the opening of the boxes facing the front.
- Reinstall the front locking access panel and lock with the key.
- Reach through each of the 3 openings and find the edge of the first bag and pull until the Puppy Glove™ logo is visible.





fig. 6





# Puppy Glove™

# 415241

## Poly Pet Station - Poly Post INSTALLATION INSTRUCTIONS

### ATTACH THE TRASH RECEPTACLE

#### ATTACH THE LID TO THE WASTE RECEPTACLE PRIOR TO MOUNTING

- Ensure the top of the trash receptacle is about 12.9" below the bag dispenser. This allows the lid to open fully without touching the dispenser.

**NOTE:** The trash receptacle lid will open to a pre-determined angle to prevent it from being over extended. The receptacle lid will hit the post when it is fully opened.

- The bottom of the can should be about 9" from the ground (fig. 6).
- Align the back wall of the receptacle to the pre-drilled holes in post. Use the 2" fender washers on the inside of the receptacle. Secure the trash receptacle using the 2½" bolts, washers and locknuts (Bag D).

### INSTALL THE LINER TRASH BAG

- Place a Puppy Glove™ Trash Receptacle Liner Bag inside the trash receptacle. Fold it over the edge of the receptacle and close the trash receptacle lid.

### MAINTENANCE

- Regular cleaning and maintenance will help expand the life of the trash receptacle.

### ENJOY THE RESULTS!

Watch pet owners use the station to keep the area clean and tidy!


#### NEED MORE BAGS?

Contact Your Chadwell Supply  
Representative or Order Online.



ChadwellSupply.com | 888.341.2423

fig. 6



## Everyone Appreciates A Clean Environment!